




输入属于NPN型，不需要外接电源，直接短接COM和X点即可




模拟量输入



0-10V模拟量输入

方向 脉冲

Y10	-	+	Y0	-	+
Y11	-	+	Y1	-	+
Y12	-	+	Y2	-	+
Y13	-	+	Y3	-	+
Y14	-	+	Y4	-	+
Y15	-	+	Y5	-	+








JT3U-34MRT-10AD-2DA

PLC运行开关



模拟量输出



产品合格证

生产日期		检验结论	合格	检验员	
------	--	------	----	-----	--